


© FLIGHT
INTERNATIONAL



KEY

- 1 Gyro-suction gauge
- 2 Airspeed indicator
- 3 Artificial horizon
- 4 Altimeter
- 5 ILS/VOR
- 6 Engine analyser
- 7 Turn co-ordinator
- 8 Directional gyro
- 9 Rate-of-climb
- 10 ILS/VOR
- 11 8-day clock
- 12 ADF
- 13 Audio selector
- 14 VHF nav/com 1
- 15 VHF nav/com 2
- 16 ADF
- 17 Transponder
- 18 Area nav
- 19 DME
- 20 Autopilot selector
- 21 Autopilot nav selector
- 22 Autopilot
- 23 Electric trim

- 24 Oil temperature gauge and ammeter
- 25 Auxiliary fuel gauge
- 26 Main fuel gauge
- 27 Fuel flow and manifold pressure
- 28 RPM
- 29 Master switch
- 30 Ignition switch
- 31 Parking brake
- 32 Throttle
- 33 Propeller-pitch control
- 34 Mixture control
- 35 Autopilot cut-off and trim switch
- 36 Transmitter button
- 37 Radio and pitot switches
- 38 Lights switches
- 39 Panel-lights rheostats
- 40 Auxiliary fuel pump
- 41 Landing-gear control
- 42 Landing-gear position indicators
- 43 Flap-position indicators
- 44 Flap selector
- 45 Circuit-breaker panel
- 46 Compass
- 47 Outside-air temperature